



Headphone driver
1/2w Microamp

Output

Plug all the way (3 clicks) with a stereo headphone cable.
2 clicks for a mono speaker cable to drive a 4, 8, or 16 ohm speaker cabinet at 1/2 watt.



Power ⊕ — ⊖

Standard 2.1mm negative tip 9 volt pedal power supply.
(Tip: can be powered directly off the optional VIB+ pedal on the Burriss Royal Bluesman amp.)

Input

Line level audio input.
Must use shielded cable (guitar patch cable).

NOTE!: Royal Bluesman Power switch MUST be in the down FX Mode if a speaker is not attached.

1/2 watt
Amp

